## Migration Intro (HA1)

Migration Intro Components List
(shown at left)

A1: Lifting Column

A2: Lifting Column Label Identification
   Intro (HA1) Primary Leg: **1A**
   Intro (HA1) Secondary Leg: **1B**

Notes:
• Intro desk uses columns labeled 1A and 1B
• This kit is not compatible with Migration SE (MG) product

B: Power Supply: North America

C: Power Cord: North America

D: 2-pin DC Power Cable

E: 6-pin Low-Voltage Cable

F: Active Touch Controller

G: Obstruction Detection Sensor*

H: T-Splitter*

J: Splitter Cable*

*Application specific; standard on widths greater than 72" wide and when the Active Touch controller is specified.

Scan to Visit

Service Parts | Troubleshooting:

Intro (HA1)
steelcase.com/
migrationcollection/
troubleshoot/intro

Troubleshooting Support
## Maintenance Kit Parts Identification
Compatible with Migration Intro, Migration Pro, Ology, Flex and Slim Leg Height-Adjustable Desks

Parts Identification

- Low-Voltage Cable
- Controller
- Sensor
- Control Module
- Lifting Column
- Foot
- Power Cord

Scan to Visit

Error Codes:
steelcase.com/errorcodes

Service Parts | Troubleshooting:

Pro (HA2)
steelcase.com/
migrationcollection/
troubleshoot/pro

Pro High-Speed (HA3)
steelcase.com/
migrationcollection/
troubleshoot/prohs

Online troubleshooting support for Ology (OL), Flex (FLX),
Slim Leg (SLHAD), SE (MG) at steelcase.com/hadsupport

Migration Pro Components List
(shown at right)

A1: Lifting Column

A2: Lifting Column Label Identification
   Pro (HA2): **21** or **22**
   Pro High-Speed (HA3): **31**

Notes:
- Label numbers must match for Migration Pro
- Ology, Flex and Slim Leg do not show identification labels
- This kit is not compatible with Migration SE (MG) product

B: Control Module: 3-leg

Note: To test individual components for 2- and 3-leg desks, the cable (D) must be plugged into port 1.

C: Power Cord: North America

D: 6-pin Low-Voltage Cable

E: Active Touch Controller

F: Obstruction Detection Sensor
   Note: Used with HA2, HA3, OL (manufactured after 10/23/23), SLHAD

G: T-Splitter*

H: Splitter Cable*

*Application specific; standard on widths greater than 78" wide and corner desks when a second sensor (F) is used.

Migration Pro (HA2)
Migration Pro High-Speed (HA3)
Others: OL, FLX, SLHAD

A1

A2
31

B

C

D

E

F

G

H